

NON-CLOG SEWAGE PUMPS





WARNING

To prevent serious accidents, disconnect the power supply before inspecting the pump.




Trouble Shooting

Read this Operation Manual thoroughly before requesting repair. Contact the dealer from whom this equipment was purchased. Servicing and troubleshooting must be handled by qualified persons with proper tools and equipment. Common faults, root causes for these, and suggested actions are provided in the table below:

| FAULT | POSSIBLE CAUSES | SUGGESTED ACTIONS |
|-------------------------------|---|---|
| Pump does not discharge water | Pump not primed | Prime the pump |
| | Faulty foot valve/blocked strainer (if used) | Check and replace foot valve/Clean strainer if required |
| | Air leakage on the suction side | Check and correct for leakages |
| | Suction lift too high | Reduce the static suction lift |
| | Suction pipe free end/Foot valve not sufficiently submerged | Lower the suction pipe free end/foot valve and ensure that the foot valve is submerged at least 1 meter below the free surface of water |
| | NRV is jammed | Check and replace |
| | No power supply to the motor | Check for availability of power |
| | Motor coil burnt | Rewind the motor |
| | Single-phase pump capacitor weak | Check and replace capacitor |
| | Low-voltage operation | Operate when the voltage increases |
| | The motor starter overload tripped | Reset the motor starter overload. If it trips again, check the voltage. |
| | Phase absent | Contact local EB representative |
| | The ELCB has tripped out | Cut in the circuit breaker |
| | Fuse has blown | Replace fuse |
| Loose connections | Tighten the electrical connections | |
| Shaft has sheared | Replace the shaft | |
| Less discharge from pump | Low-voltage operation | Check and wait for voltage to increase. Contact local EB representative if required. |
| | Wrong direction of rotation | Interchange the supply connections of any two phases. |
| | Static suction lift high | Lower the pump set or wait for water level to rise |

| | | |
|---------------------------------|--|---|
| | Total head higher than specified head | Wrong selection |
| | Leaky pipes | Change leaky pipes |
| | Smaller pipe size used when compared to nameplate recommendations | Replace with suggested pipe size |
| | Discharge pipe internally coated with depositions | Clean the pipe |
| | Foreign bodies lodged in impeller/casing | Check the impeller/casing and remove the foreign bodies |
| | The valve in the discharge pipe is partly closed/blocked | Check and clean/replace the valves if necessary |
| | Impeller is worn out | Check and replace |
| Total head developed is too low | Clearance between pump impeller and wear plate increased | Check and replace worn out parts |
| | Abrasive and or corrosive wear of pump hydraulics | Change the worn out pump parts |
| | Change in the static head | Check the actual static head. |
| | Running at low-voltage | Wait for voltage to increase or contact local EB representative |
| Current consumption in excess | Single phasing. | Check line fuses / availability of Three-phase supply. |
| | Voltage too low, | Check the voltage. |
| | Defective rotor | Change the rotor. |
| | Rotor rubbing against stator ID due to bend | Check and replace the rotor |
| | Low system head and therefore higher discharge | Throttle the discharge |
| Pump runs rough and noisy | Pump bearings worn out. | Dismantle and replace worn out bearings |
| | Pump cavitating due to high suction lift | Reduce static suction lift. |
| | Pump not grouted | Grout the pump |
| | Rotor shaft is bent resulting in rotor rubbing against stator bore | Replace rotor shaft |
| | Impeller rubbing against casing | Check impeller sealing/wearing ring run out. If excessive, replace impeller. Check rotor run out at location of impeller. If excessive, replace rotor. |
| Pump leaks excessively | Gland not adequately tightened | Tighten the gland |

| | | |
|--|--|-----------------------------------|
| | Packing Rope and shaft sleeve worn out | Replace packing Rope and Oilseal |
| | Casing gaskets damaged | Check and replace gaskets |
| | Pipeline damaged | Check and replace piping |
| | Mechanical Seal damaged | Check and replace Mechanical Seal |

| | |
|--|--|
|  NOTE | Conduct trial operation after maintenance. |
|  NOTE | Dispose replaced components with appropriate care so as to protect the environment. |
|  WARNING | Do not try to solve unspecified troubles of pump as it may lead to severe damage to the pump or injury to personnel. Contact the dealer from whom this pump was purchased. |