


Borewell Compressor Pumps

Instruction &
Operating Manual



**Texmo
Industries**
Est. 1956



Table of Contents

- 1.** Introduction
- 2.** Warranty information
- 3.** Complying with standards
- 4.** Contents in the packing box
- 5.** Information about your pump
- 6.** Schematic drawings
- 7.** Key product specifications & features
- 8.** Cross-section view
- 9.** Pre-installation requirements
- 10.** Installation procedures
- 11.** Basic troubleshooting
- 12.** Preventive maintenance checks
- 13.** Do's and don'ts
- 14.** Important safety instructions
- 15.** Storage & handling
- 16.** Company contact information

1. Introduction

Thank you for choosing a quality product manufactured by Texmo Industries. We request you to read this manual carefully to ensure that the system you have purchased will be operated correctly.

This manual is intended to provide you with information on your product and information on installation and operation. You will also find information on how you could contact Texmo Industries, should you need further information or help and support.

2. Warranty information

Please refer to your warranty card or visit **www.taropumps.com** for more information on your warranty.

3. Complying standards

IS 996: Single Phase A.C. Induction Motors for General Purpose
IS 3043: Code of Practice for earthing - Specification
IS13730: Specifications for Particular Types of Winding Wires

4. Contents of the packing box

Based on model you have purchased, your Compressor is packed along with instruction manual and warranty card in either a corrugated box or in a wooden crate.

5. Information about your pump

Compressed air, pumped down the well, is mixed with water in the discharge pipe as very fine air bubbles by the air distributor installed at the end of the air pipeline. The air-water mixture has a lower density than water in the surrounding water column and so the air-water mixture rises in the discharge pipe and eventually flows out of the pipe. The outlet from the discharge pipe should never be connected to a pipeline running over a long distance since this will cause hammering as the water is ejected due to large air pockets formed during horizontal travel of air-water mixture. The flow of water is not continuous and delivery of water depends on the yield and water level in the bore well.

Taro Borewell Compressors are designed for pumping water from deep wells of up to 400 feet. Borewell Mono compressor pumps are designed for domestic purpose of pumping water from bore wells. These Borewell Mono compressor pumps are coupled directly to the motor for higher operating efficiency. Our compressors are sound in design and robust in construction and are manufactured and tested to high standard of excellence. They give satisfactory service with proper installation and normal routine maintenance.


TABLE 1, shown below, indicates the range of Borewell Compressor Pumps offered by us. Selection is based on the availability of power, Single/Three Phase, and on the air displacement volume.

Type	HP	No. Of Cylinders	Compressor Speed rpm	Motor Speed rpm	Pressure kg/cm ²	Belt Size	Lubrication Oil Capacity mL	Air Displacement lpm
TMC 07N	1	1	1440	1440	7	NA	250	123.6
TMC 1N	1.5	1	1440	1440	7	NA	250	178
TBC 07N	1	1	1000	1440	9	A47	180	113
TBC 11N	1.5	1	820	1440	9	A42	200	144
TBC 15N	2	2	900	1440	10	B42	300	219
TBC37N	5	2	930	1440	9	A70	650	608

6. Schematic drawing

View of a Borewell Mono and Belt Compressor is shown below in Fig. 1:

Fig. 1 View of Borewell Mono and Belt Compressor



7. Key specifications & features

Standard Specification of Compressor is shown below in TABLE 2:

Single Phase Mono-compressor	1.0 and 1.5 HP
Single Phase Belt Driven Compressor	1.0 and 1.5 HP
Three Phase Belt Driven Compressor	2.0 and 5.0 HP
Motor Type – 1Ø Mono-Compressor	Squirrel Cage Induction Motor – Capacitor Start Capacitor Run
Operating Voltage: 1Ø Mono-Compressor	180 – 240V
Frequency	50 Hz
Speed	1440 rpm
Duty	S1 Continuous

Key features: Monoblock Compressor Pump

- ✓ Compressor mounted on the motor shaft and so belt drive is not required, resulting in no slip and higher overall efficiencies
- ✓ The motor is a single phase squirrel cage induction motor with capacitor start capacitor run.
- ✓ The motor shaft is supported on two deep groove ball bearings provided with double shields to retain the high temperature grease
- ✓ The rotors are dynamically balanced.
- ✓ Adequate motor surface area is provided for effective cooling
- ✓ To prevent oil from entering the motor, an oil seal is provided


Key features: Belt Driven Compressor Pump

- ✓ Both single phase and three phase models are available
- ✓ Twin cylinder compressors are connected by intercooler for improved efficiency
- ✓ Adequate motor surface area is provided for effective cooling
- ✓ Fan guard provided to protect personnel from visible rotating parts and accidental contact with hot surfaces

8. Cross-section view

Cross-section view of a Single Phase Mono Compressor is shown below in Fig. 2:


Fig. 2 Cross-section view of single phase mono compressor



No.	PART NAME	No.	PART NAME	No.	PART NAME
1	Air Filter Unit	14	Cotter Pin	27	Spider Washer
2	Oil Breather	15	Bearing	28	Needle Roller
3	Gudgeon Pin	16	Rear Cover	29	Connecting Rod
4	Piston Ring-Compression	17	Hexagon Bolt	30	Connector
5	Piston Ring - Scraper	18	Lock Washer	31	Reducer
6	Piston	19	Centrifugal Switch	32	Drain Plug
7	Piston Ring - Oil	20	Terminal Box	33	Sight Glass
8	Cylinder Head	21	Rotor With Shaft	34	Crank Case
9	Middle Plate	22	Stator	35	Stud
10	Cylinder	23	Oil Seal	36	Spring Washer
11	Hex Socket Set Screw	24	Circlip	37	Hexagon Nut
12	Fan Guard	25	Crank Web	38	Air Cock
13	Fan	26	Oil Splasher	39	Valve Blade

Cross-section view of a Single Phase Belt Driven Compressor is shown below in Fig. 3:


Fig. 3 Cross-section view of single phase, single cylinder belt driven compressor



No.	PART NAME	No.	PART NAME	No.	PART NAME
1	Base Plate	11	Crank Case	21	Piston Ring -Compression
2	Motor Pulley	12	Crank Shaft	22	Center Plate
3	Washer	13	Fan	23	Fan Guard
4	Rail	14	Fan Pulley	24	Clamp
5	Hexagon Bolt & Nut	15	Housing	25	Valve Blade
6	Drain Plug	16	Circlip	26	Gudgeon Pin
7	Sight Glass	17	Oil Seal	27	Oil Breather
8	Stud	18	Cylinder	28	Air Filter Unit
9	Connecting Rod	19	Piston Ring - Oil	29	Cylinder Head
10	Oil Splasher	20	Piston Ring Scraper	30	Air Cock

Cross-section view of a Three Phase Belt Driven Compressor is shown below in Fig. 4:

Fig. 4 Cross-section view of three phase, twin cylinder belt driven compressor



No.	PART NAME	No.	PART NAME	No.	PART NAME
1	Base Plate	16	Intercooler Nipple	31	Circlip
2	Motor Pulley	17	Copper Washer	32	Gudgeon Pin
3	Rail	18	Intercooler	33	Fan Pulley
4	Hexagon Bolt	19	Reducer Elbow	34	Oil Seal
5	Hexagon Nut	20	Coupling	35	Bearing
6	Washer	21	Connector	36	Fly End Cover
7	Drain Plug	22	Oil Breather	37	Crank Web
8	Sight Glass	23	Air Cock	38	Needle Roller
9	Crank Case	24	Cylinder Head	39	Spacer
10	Stud	25	Fan Guard	40	Spider Washer
11	Connecting Rod	26	Fan	41	Free End Cover
12	Air Filter Unit	27	Center Plate	42	Connector
13	Piston	28	Piston Ring	43	Valve Blade
14	Clamp	29	Piston Ring Scraper		
15	Intercooler Nut	30	Piston Ring - Oil		

9. Pre-installation requirements

Arrangement for Installation

- ✓ Use the services of a professional and trained mechanic with experience in erecting Borewell Compressor Pumps
- ✓ Ensure proper safety during installation
- ✓ Ensure that a foundation is available for mounting of the Compressor Pump
- ✓ While installing the Compressor Pump, ensure that it is not subject to shock loads which can damage the parts
- ✓ Use appropriate lifting equipment

General Installation Precautions

- ✓ Open the packaging, check the contents and note down the Serial number and Model for future reference
- ✓ Ensure all fasteners are tightened properly
- ✓ Check for oil leaks
- ✓ Use prescribed pipe sizes as mentioned on the product name plate
- ✓ Use a power cable, without joints, from the pump set to the starter. It is not recommended to use a power cable with large number of joints as this can result in a significant voltage drop.
- ✓ Check the availability of single / three phase power
- ✓ Ensure availability of a starter with inbuilt single phase preventer, overload protection and high voltage and low voltage protection for three phase products
- ✓ It is recommended to place the compressor pump set on a concrete foundation





Note

If you detect damage or discrepancy in the product, contact the dealer from whom the pump was purchased

 Caution	Ensure suitable precautions are taken while lifting and lowering the product.
 Caution	Use trained professionals to install the compressor pump.
 Warning	Use a power supply cable that has sufficient rating. Factor in low voltage operation.
 Warning	Provide proper earthing. Improper earthing can cause electrical shock.
 Caution	Use a megger to verify the insulation resistance of the motor. Insulation resistance should be 20MΩ minimum.
 Caution	Check the level of oil in the crank case before powering up the compressor pump.
 Warning	Mount the compressor pump with the motor axis parallel to the foundation.

Operation Precautions

 Warning	Switch OFF the power before working on electrical lines
 Note	For three phase models use a starter



Caution

The crank case is filled with oil for lubricating the cylinder walls as also the big end and small end bearings on the connecting rod. Do not run the compressor pump if the crankcase is not filled or has low oil level in the crank case as the bearings and cylinder walls can get damaged due to dry running.



Note

During operation, if there is a power shut down, the motor will stop. On resumption of power, do not power up the motor. First, open the air cock and release all the compressed air. Then shut off the air cock and then power up the compressor motor.



Caution

Ensure proper direction of rotation of the compressor pump on powering up.

10. Installation procedure

Please follow the below procedure to install the Borewell Compressor Pump.



Caution

The supply voltage should be within the specified voltage range. Failure to ensure the above could cause the compressor pump to malfunction and may lead to current leakage or electrical shock.




Warning


If you find any abnormalities like vibration, noise, smell, etc. from the pump set during trial operation, switch OFF the pump set and contact the dealer from whom this pump was purchased.

Bolt down the Monoblock Compressor Motor base / Base Plate of belt driven compressors using the foundation bolts as shown in Fig. 5 and Fig. 6, shown below.

Fig. 5 Installation of monoblock compressor pump



✓ Fig. 6 Installation of belt driven compressor pump



Installation:

- ✓ Ensure sufficient space around the compressor so that ventilation is proper
- ✓ Ensure a level foundation with foundation bolts for assembling the compressor pump
- ✓ Open the Oil Breather and top up, if necessary, the crank case with oil of specified grade up to the level marked on the sight glass
- ✓ Measure the Insulation Resistance using a megger of 500 VDC
- ✓ Ensure that the insulation resistance, as shown on the megger, is a minimum of 20MΩ
- ✓ Check the direction of rotation of crank matches the direction marked on the crank case
- ✓ Use suggested pipe sizes for air pipe and water pipe (Refer Table 5)

Recommended lubricants

Ambient Temperature °C	ISO VG No.	Bharat Petroleum	Hindustan Petroleum	Indian Oil	Castrol
10 - 25	ISO 100	Hydrol 100	Enklo 100	Servo Press 100	Perfecto T 100
25 - 80	ISO 150	Hydrol 150	Enklo 150	Servo Press 150	Hyspin AWS 150


NOTE:

- ✓ Lubricating oil is poured into the crankcase by removing the oil breather
- ✓ Lubrication oil is drained by removing the drain plug
- ✓ Always top up with the same grade of oil available in the crank case


Oil filling / removal

Monoblock Compressor Pumps and Belt Driven Compressor Pumps are prefilled with the specified quantity and grade of oil prior to dispatch from the factory. The sight glass has a red circle marked on it. Observe the level of oil through the sight glass. If the oil level is within this circle, then there is no need to top up the oil. In case the oil level drops below the red circle, top up is required. Top up is possible by removing the Oil Breather and pouring oil into the reducer as shown in Fig. 7 and Fig. 8. After top up, replace the Oil Breather.

✓ **Fig. 7 Filling / topping up the crank case of monoblock compressor pump**



✓ **Fig. 8 Filling / topping up the crank case of belt drive compressor pump**



To reduce the oil level or drain the oil, remove the drain plug. Re-fit after draining.

Foundation details for mono compressor pumps and belt driven compressor pumps are shown below in TABLE 4.

Refer Fig. 4 and Fig. 5

Type	A	B	C	D	ØE	Tolerance on A & B
TMC 07 N	140	190	260	210	Ø11	±0.30
TMC 1 N	140	190	260	210	Ø11	±0.30
TBC 07 N	187	355	520	280	Ø13	±2
TBC 11 N	194	430.5	600	280	Ø13	±2
TBC 15 N	194	430.5	600	280	Ø13	±2
TBC 37 N	271	790	1000	360	Ø14	±2

Recommended air and water pipe sizes are shown below in TABLE 5:

Compressor HP	Air pipe size OD in mm	Water pipe size OD in mm
1 - 2	16	32
5	20	50

Pipe selection

Air pipe working pressure Minimum 10 kg/cm² (HDPE) Minimum 15 kg/cm² (PVC)

Water pipe working pressure Minimum 4 kg/cm² (HDPE) Minimum 6 kg/cm² (PVC)

NOTE: Use at least 25 - 30 feet GI pipe from the compressor pump outlet as it withstands heat better. HDPE is preferable for the air pipe and water pipe located inside the bore well.

Cable selection

The motor for both single and three phase compressor pump requires a 3 core PVC insulated cable. Refer to TABLE 6, shown below, for selection of cables:

S. No	HP	Phase	Cable Size mm ²
1	1	1	1.5
2	1.5	1	1.5
3	2	3	1.5
4	5	3	2.5

Checking direction of rotation of Compressor



Danger

Hazardous voltage - Will cause death, serious injury, electrocution. All electrical work must be performed by an authorized electrician, in compliance with local electrical equipment standards and internal wiring codes.

- ✓ Connect the pump set to the starter, power up the compressor pump and observe the direction of rotation of the fan
- ✓ If the fan rotates in the same direction as the arrow marked on the crank case, this is the correct direction of rotation
- ✓ In case the fan rotates opposite to the marked arrow on the crank case, then this is the wrong direction
- ✓ In case of wrong direction of rotation, interchange any two phase wires. Power up the compressor pump and observe the direction of rotation of the fan. This should match the arrow direction marked on the crank case.
- ✓ Never run the compressor pump with crank case without oil or oil lower than the specified level

Electrical Installation

- ✓ Check the power supply voltage and frequency and compare with the product requirements specified on the name plate.
- ✓ Observe relevant EB regulations while giving power supply to the motor.
- ✓ As far as possible, do not use multiple joints in the electrical cabling while connecting the starter to the pump set.
- ✓ Ground the pump set using the two earth screws provided on the delivery chamber
- ✓ Ensure electrical joints, if any, are properly and adequately insulated
- ✓ While making the electrical connections, avoid loose connections
- ✓ Factor in low voltage operation while selecting cable size

Electrical wiring work



Warning

All electrical work must be performed by an authorized electrician in compliance with local electrical equipment standards and internal wiring codes. Improper wiring can lead to current leakage, electrical shock, or fire.

Earthing



Warning




Be sure to install the ground wire securely. Failure to observe this precaution could damage the pump and cause current leakage, which may cause electrical shock.



Caution

Do not connect the ground wire to a gas pipe, water pipe, lightning rod, or telephone ground wire. Improper grounding could cause electrical shock.

Connecting the Power Supply

	<p>Observe relevant Electricity Board regulations while powering up the pump set</p>
	<p>Before inserting the power plug or connecting the wires to the terminal board, make sure the power supply is properly disconnected. Failure to do so may lead to electrical shock, short, or injury caused by the un-intended starting of the pump.</p>
	<p>Do not use damaged cables, power plugs, or loose power outlets. Failure to observe this precaution could lead to electrical shock, short circuit or fire.</p>


Pulley positioning, alignment and belt tensioning

It is essential to ensure the compressor pump has an adequate degree of protection from dust and water. Ensure that the compressor pump has no obstruction around it as this can reduce the free circulation of cooling air. The motor drives the compressor through a belt drive. The motor pulley and compressor fan pulley must be properly aligned. The motor and compressor shafts must be parallel to each other. The belt should not be overly stretched or tensioned. To assemble the pulley on the motor shaft, insert the pulley halfway up the keyway manually. Intense hammering should be avoided during fitting of pulley as this process can result in damage to the raceways over a period of time.

Refer Fig. 9 for pulley positioning and alignment.

➤ Fig. 9 Pulley positioning and alignment


Belt tension is provided by adjusting the center distance between the compressor and motor. The compressor is firmly bolted to the base plate, while the motor is moveable. Use the bolts to adjust the position of the motor and therefore the belt tension. If the belt tension is slack, the belt can slip. If the belt tension is too high, the bearings can get overloaded leading to premature failure.



Refer to Fig. 10 for tensioning the belt:

- ✓ The assembled compressor with fan and the rails for mounting of the motor are located on a base plate.
- ✓ The base plate is fixed to the concrete foundation using the four foundation bolts.
- ✓ Mount the motor and clamp it to the rails using the 4 sets of bolt, nut and washer.
- ✓ Mount the Motor Pulley on the motor shaft and ensure that it is aligned with the fan pulley.
- ✓ Install the V-Belt to pass over the two pulleys.
- ✓ Using the pre-tensioning bolt with nut, push the motor away from the compressor till the belt is properly tensioned. Tighten the nut to prevent the bolt from loosening during operation.
- ✓ Now clamp the rails to the base plate using the 4 sets of bolt with washer and nut.

✓ **Fig. 10 Belt tensioning**



11. Basic troubleshooting



Warning

To prevent serious accidents, disconnect the power supply before inspecting the Borewell Compressor Pump.

Read this Operation Manual carefully before requesting repair. Contact the dealer from whom the pump was purchased. Servicing and troubleshooting must be handled by qualified persons with proper tools and equipment. Common faults, root cause for these and suggested actions are provided in TABLE 7 below:

Fault	Possible Causes	Suggested Actions
Compressor Pump Overheats	Dirty oil	Change oil
	Oil level LOW	Fill correct grade of oil up to the maximum mark on the oil level indicator
	Cylinder and intercooler fin dirty	Clean the fins
	Recommended air pipe not used	Fit the recommended pipe sizes
	Located in a closed room with no ventilation	Improve the ventilation
Oil contamination in compressed air	Breather valve not working	Clean the breather valve and refit after checking
	Choked Air Filter	Clean the air filter/ replace it
	Oil level HIGH	Drain excessive oil
	Piston Rings end gap may be inline	Change the piston rings end gap
	Oil viscosity too low	Use recommended oil grade
	Piston Rings are broken or stuck in grooves	Remove the piston and loosen the rings. Replace if broken. Check all related parts for wear before fitting.
	Piston to cylinder clearance excessive	Change as required.

Fault	Possible Causes	Suggested Actions
Compressor Pump knocking	Worn out piston, cylinder, crank shaft and connecting rod bearings	Overhaul the pump
	Piston to Cylinder clearance excessive	Change as required
	Fan - Fly Wheel loose	Remove fan-fly wheel and examine key-way and key for wear
Water discharge is poor	Leaky joints in pressure lines	Leak proof the identified leaky joints
	Improper seating of inlet and outlet delivery blades	Dismantle and seat the blades and reassemble
	Worn out piston rings	Replace the rings as a set
	Loose belts	Adjust or replace if elongated
Unusual wear of cylinder, piston and piston rings	Inadequate air filter maintenance	Clean the air filter frequently
	Insufficient frequency of oil change	Check the oil frequently and change when necessary
	Incorrect grade of oil	Use grade of oil
Water or rust formation in crankcase	Faulty breather	Check and replace breather if necessary
Excess belt wear	Incorrect motor and compressor pump pulley alignment.	Check and adjust using a straight edge/string across the diameter of both pulleys
	Incorrect belt tension	Check belt adjustment frequently

Fault	Possible Causes	Suggested Actions
Oil leak through breather	Breather valve not working	Open, clean and refit the breather
	Piston rings are broken or stuck in grooves	Remove the piston rings and replace as a set
	Piston to cylinder clearance excessive	Inspect and change the non-conforming components
	Oil level HIGH	Drain till the correct level is achieved
Oil leak past Oil Seal	Dirt in the crankcase	Drain the oil, clean the crankcase and replace with fresh oil
	Dust deposits on Oil Seal outside	Clean the dirt near the oil seal
	Alignment between motor pulley and compressor pulley incorrect	Correct the alignment between the pulleys
	Excessive belt tension	Adjust the belt tension for 10mm play
Oil leak through cylinder Head and Inter-Cooler Joints	Choked air filter	Clean/replace the air filter
	Oil level HIGH	Drain till correct level is achieved
	Dust deposits on the compressor	Clean the compressor regularly
	Lower cooling of compressor pump	Increase cooling by providing sufficient space around the compressor

NOTE: Not applicable to Monoblock Compressor Pumps



Note

Conduct trial operation after maintenance



Note

Dispose replaced components/oil with appropriate care so as to protect the environment



Warning

Do not try to solve unspecified troubles of the Borewell Compressor Pump set as it may lead to severe damage to the pump or injury to personnel. Contact the dealer from whom the pump set was purchased.






Caution

If the Borewell Compressor Pump runs with unusual noise, stop it immediately.





12. Preventive maintenance checks

Precautions to be taken



 Warning	<p>Disconnect the power supply before starting maintenance or inspection of the Borewell Compressor Pump to avoid electrical shock.</p>
 Warning	<p>During operation, the compressor gets hot. Cool before working on the compressor.</p>
 Note	<p>If you find any damages or abnormalities, switch OFF the Borewell Compressor Pump and report the problem to the dealer from whom the set was purchased.</p>

NOTE: The manufacturer assumes no responsibility for damage or injury due to disassembly in the field.

A definite schedule of preventive maintenance inspections should be established to avoid breakdown, serious damage and extensive downtime. The schedule will depend on operating conditions and experience with similar equipment. Below check list does not represent an exhaustive survey of maintenance steps necessary to ensure safe operation of the pump set.

 Warning	<p>The Borewell Compressor Pump must not be operated with the delivery valve shut-off for more than a few seconds; otherwise the motor will overheat, possibly causing permanent damage.</p>
 Warning	<p>Utilize the services of an electrician to carry out electrical measurements / checking the functioning of the starter</p>

It is good practice to monitor the conditions and performance of the pump set. Diagnosis may be carried out by checking the following:

-  Check the direction of rotation of the pump set
-  Check all electrical connections are proper

Daily checks

- ✓ Clean the compressor pump thoroughly
- ✓ Check the oil level in the crankcase. If required, replenish with the right grade and quantity of oil
- ✓ Check the belt tension

Monthly checks

- ✓ Check the air filter, clean the filter mesh in kerosene, dry and then refit
- ✓ The breather valve should be dismantled, cleaned and checked for perfect seating of valve
- ✓ All the pipe joints should be checked for leakage

Every 500 hours of operation

- ✓ Check if there is unusual operational noise and vibration of the compressor pump
- ✓ Check if all mounting bolts and other fasteners are tight
- ✓ Check if there are air leaks from pipe joints, intercooler and air cock
- ✓ Clean the air filter. If the air filter element is contaminated, replace it
- ✓ Examine the lubricating oil in the crank case. If necessary, drain and refill. The compressor should be run for some time and draining the oil should be done when the oil is warm

Note:

- ✓ First oil change shall be done after 150 hours of operation.
- ✓ The subsequent oil change shall be carried out every 500 hours of operation
- ✓ Not applicable to Monoblock Borewell Compressor Pumps

13. Do's and don'ts

Do's	Dont's
Before installation, rotate the shaft to ensure that compressor pump is not jammed	Do not run without fan guard
Ensure proper earthing is provided	Do not place the product in a poorly ventilated space
Mount the compressor pump on a concrete foundation.	Do not have multiple joints on the cable. More the cable joints, more will be the voltage drop.
Ensure the compressor pump runs in the right direction.	Do not run the product without air filter
First oil change is after 150 hours of operation.	Do not start the product with back pressure. Release the air by opening the air cock and re-start.
Subsequent oil changes should be carried out once every 500 hours of operation.	Do not earth to a water line or gas line
Inspect the air filter regularly. Clean if required. If not, replace the filter element.	Do not use undersized electric cables. Factor in low voltage usage.
Check the drain and filling plugs for tightness before erection.	Do not run the compressor pump if the oil level in the sight glass is below the prescribed level
Check for oil leak through breather	Do not run with air cock open
Check for oil leak into the motor	Do not run with over tight belts
Oil contamination in compressed air	Do not run with loose belts

14. Important safety instructions

Only qualified personnel should be involved for inspection, maintenance and repairs. The successful and safe operation of such a product depends on proper handling, installation and maintenance. It is suggested that in case of non-functioning of the product, the customer is requested to contact the dealer through whom the purchase was made.



Danger

Hazardous voltage - Will cause death , serious injury, electrocution
Disconnect all power before working on this equipment
Maintenance should be performed by only qualified personnel



Caution

Hot surfaces. Do not touch.

15. Storage & Handling

- ✓ The products are supplied from the factory in proper packing in which they should remain until they are to be installed.
- ✓ The product should be stored in a closed, dry and well ventilated room.
- ✓ Do not store the products in direct sunlight.
- ✓ Handle the Borewell Compressor Pump with care and do not expose the product to unnecessary impact and shocks.
- ✓ During unpacking and prior to installation, care must be taken when handling the Borewell Compressor Pump to ensure that the product is not subjected to shock loads.
- ✓ If the product has been stored for a very long period, check for free rotation of the shaft and level of oil inside the crank case.



Caution

If the compressor is stored, the shaft must be turned by hand at least once a month



Caution

If the compressor has been stored for more than one year before installation, dismantle the motor and check the rotating parts before use.



Caution

After a long period of storage, the compressor should be inspected before it is put in operation. Ensure the impeller can rotate freely when turned by hand.



Caution

For mono compressors, an Oil Seal is provided to prevent oil from leaking into the motor. For belt driven compressors, the oil seal prevents oil from leaking into the environment. Check the condition of the oil seal if the product has not been use for a long period of time.

16. Company contact information

For most up to date information on contacting Texmo Industries, please go to www.taropumps.com



P.B.No. 5303,
Mettupalayam Road,
Coimbatore - 641 029, India

1800-102-8888
www.taropumps.com
info@taropumps.com



**Texmo
Industries**
Est. 1956