

# Three Inch Borewell Submersible Pump Sets

Instruction &  
Operating Manual



**Texmo  
Industries**  
Est. 1956







# Table of Contents

---

- 1.** Introduction
- 2.** Warranty information
- 3.** Complying with standards
- 4.** Contents in the packing box
- 5.** Information about your pump
- 6.** Schematic drawings
- 7.** Key product specifications & features
- 8.** Cross-section view
- 9.** Pre-installation requirements
- 10.** Installation procedures
- 11.** Basic troubleshooting
- 12.** Preventive maintenance checks
- 13.** Do's and don'ts
- 14.** Important safety instructions
- 15.** Storage & handling
- 16.** Company contact information

# 1. Introduction

---

Thank you for choosing a quality product manufactured by Texmo Industries. We request you to read this manual carefully to ensure that the system you have purchased will be operated correctly.

This manual is intended to provide you with information on your product and information on installation and operation. You will also find information on how you could contact Texmo Industries, should you need further information or help and support.

# 2. Warranty information

---

Please refer to your warranty card or visit **[www.taropumps.com](http://www.taropumps.com)** for more information on your warranty.

# 3. Complying standards

---

IS 694: Polyvinyl Chloride insulated unsheathed and sheathed cables / cords with rigid and flexible conductor for rated voltages up to and including 450/750 V

IS 3043: Code of Practice for earthing: Specifications

IS 8034: Submersible Pumpsets: Specifications

IS 9283: Motors for Submersible Pumpset: Specification

# 4. Contents of the packing box

---

Based on model you have purchased, your Borewell Submersible is packed along with instruction manual and warranty card in a corrugated box

## 5. Information about your pump

---

Taro Borewell Submersible pumpsets are manufactured using high quality raw materials and components using state-of-the-art manufacturing facilities. Taro Borewell Submersible pumpsets will give trouble free performance if they are properly installed and maintained. Prior to installation, go through this manual thoroughly and follow the instructions for installation and maintenance of our submersible pumpset so as to ensure reliable operation.

Applications include domestic and community water supply, water supply to high rise buildings, municipal water supply, industrial water supply.


The submersible pumpset should be installed by technically qualified personnel in compliance with national and local electrical codes and as per our instructions in order to avoid electrical shocks, unsatisfactory performance and equipment failure.

## 6. Schematic drawing

---

View of a 3 inch Submersible Pump Set is shown below in Fig. 1:

**Fig. 1 View of 3 inch Submersible Pump Set**



## 7. Key specifications & features

---

Standard Specification of 3 inch Borewell Submersible Pumps is shown below in TABLE 1:

Phase and Power	Single Phase: 1.0 HP
Motor Type	Wet
Starting method	DOL
Operating Voltage	Single Phase Premium: 180 – 240 V Power: 180 – 240 V Prime: 160 – 220 V
Frequency	50 Hz
Speed	2850 rpm
Duty	S1 Continuous
Max. Fluid Temperature	33°C
Impeller Type	Radial
Cable	3 Core PVC Insulated flat cable

### Product Performance Specification

---

Texmo Industries has a wide variety of 3 inch Borewell Submersibles to meet your requirements. Please consult our sales team / your nearest dealer to meet your specific requirements.

### Key features: Motor

---



Motor is filled with a mixture of pure clean water mixed with anti-corrosive liquid for improved motor life



The motor houses water lubricated journal and thrust bearings



The stator winding is water cooled and is made from poly-wrapped copper wire

- ✓ Oil seal and sand guard is provided to prevent sand entry
- ✓ High grade carbon thrust bearing enables reliable operation
- ✓ Winding over hang protector provided to ensure the coil life
- ✓ LTB 4 journal bearing bushes for longer life of motors
- ✓ Motors fitted with copper rotor
- ✓ Easily re-windable Squirrel-cage motor
- ✓ Equipped with rubber diaphragm to compensate thermal expansion of water
- ✓ High quality seal rings and sand guard to protect motor from sand entry

### Key features: Pump

---

- ✓ Special nitrile rubber bearing bushes for high wear resistance
- ✓ Built-in NRV with low head loss design
- ✓ Pumps fitted with high quality engineering polymer NORYL GF 30% impellers and diffuser housings
- ✓ TBRT Series pumps are provided with Stainless Steel clad Noryl diffusers
- ✓ Stainless Steel pump shell for enhanced corrosion resistance
- ✓ Stainless steel shaft for enhanced corrosion protection
- ✓ Counter thrust collar to limit up-thrust



### **Key features: Strainer**

---



A Stainless Steel strainer, wrapped around the Inlet Bracket, prevents the ingress of pebbles into the intake during pumping

### **Key features: Wiring Harness**

---




All submersible motors are provided with 3 core PVC insulated flat cable of length 3 metres

## 8. Cross-section view

Cross-section view of 3 Inch Submersible Motor assembled with Double D coupling mounted on the shaft is shown below in Fig. 2:


**Fig. 2 Cross-section view of 3 inch submersible motor**



PART No.	PART NAME
1	Coupling
2	Hex. Nut
3	Sand Guard
4	Hex Socket Head Cap Screw
5	Bush
6	Cable
7	Stud
8	Cable Gland Bush
9	Cable Gland
10	Oil Seal
11	Top Housing
12	Intermediate Shell - Top
13	Wdg Overhang Protector
14	Rotor With Shaft
15	Stator Stack With Winding
16	Stator Housing Shell
17	Intermediate Shell - Bottom
18	Bottom Housing
19	Parallel Key
20	Thrust Collar
21	Carbon Thrust Unit Assy
22	Thrust Insert
23	Diaphragm
24	Motor Base

Cross-section view of 3 Inch Submersible radial flow pump, TRT Series, is shown below in Fig. 3:


**Fig. 3 Cross-section view of 3 inch submersible radial flow pump – TRT series**



PART No.	PART NAME
1	Cable Guard
2	Cable Clamp With Screw
3	Hexagon Bolt
4	Nrv Cup Washer
5	Hexagon Nut
6	Sleeve
7	Thrust Collar
8	Bush
9	Inlet Seal Ring
10	Distance Sleeve
11	Strainer
12	CH Screw
13	Delivery Casing Outer
14	Delivery Casing Inner
15	Non - Return Valve
16	Lock Nut
17	Pump Housing
18	Impeller
19	Diffuser Housing
20	Intermediate Housing
21	Lock Pin
22	Pump Housing Shell
23	Shell Locking Nut
24	Hex Socket Head Set Screw
25	Hex Socket Head Cap Screw
26	Inlet Bracket

Cross-section view of 3 Inch Submersible Box type radial flow pump, TBRT Series, is shown below in Fig. 4:




**Fig. 4 Cross-section view of 3 inch submersible box type radial flow pump – TBRT series**








PART No.	PART NAME
1	Cable Guard
2	Cable Clamp With Screw
3	Tie Bar
4	CSK Screw
5	Hexagon Nut
6	Pump Housing - Bush
7	Thrust Collar
8	Impeller Sealing Plate
9	Inlet Bracket
10	Strainer
11	CH Screw
12	Delivery Casing Outer
13	Hexagon Nut
14	NRV Cup Washer
15	NRV
16	Delivery Casing Inner
17	Lock Nut
18	Pump Housing
19	Sleeve
20	Impeller
21	Diffuser Housing
22	Lock Pin
23	Distance Sleeve
24	Hex Socket Head Set Screw
25	Hex Socket Head Cap Screw




# 9. Pre-installation requirements

## Arrangement for Installation



-  Use the services of a professional and trained mechanic with experience in erecting borewell submersibles
-  Ensure proper safety during installation
-  Ensure the availability of electrical power as indicated in Table 1

## General Installation Precautions





-  Open the packaging and note down the serial number and model for future reference
-  Inspect the purchased pump for damage / leakage
-  Ensure all fasteners are tightened properly
-  Check the inside diameter of the well casing to ensure that it is not smaller than the size of the submersible
-  Check depth of borewell to determine the length of piping and power cable required

 Note	If you detect damage or discrepancy in the product, contact the dealer from whom the pump was purchased
 Warning	Do not use this pump for oil or toxic, acetic, corrosive and flammable liquids. Pumping flammable liquids could cause explosion
 Caution	Do not use the pump cable for lifting / lowering the pump



 Caution	Use trained professionals to install the submersible pump. Improper fitment can cause the pump to fall into the bottom of the bore
 Warning	Use a power supply cable that has sufficient rating and has been exclusively provided for the pump. Factor in low-voltage operation
 Warning	Provide proper earthing as improper earthing can cause electrical shock
 Caution	Use a Megger to verify the insulation resistance of the motor. Insulation resistance should be 20MΩ minimum
 Caution	Do not place the submersible pump with its base resting at the bottom of the borewell. There is a possibility for the motor and pump to be buried in the silt which collects at the bottom of the borewell
 Note	Mount the pump vertically. Never inclined or horizontal

Operation Precautions

 Caution	Do not run the pump dry. It could lead to product damage
 Warning	Switch OFF the power supply and ensure that the impeller completely stops before making adjustments
 Caution	Do not use this pump for pumping liquid exceeding 33°C as this may lead to product failure
 Warning	Do not switch ON the pump if there is any human contact with the pumped medium. If any electrical leakage occurs, this could be fatal

## 10. Installation procedure

---

Please follow the below procedure to install the pump and motor.



Caution


The supply voltage should be within -15% to +6% of rated voltage.  
Water temperature for operation of the pump should not exceed 33°C.  
Failure to observe the precautions given above could cause the pump to malfunction, which may lead to current leakage or electrical shock.

### Installation

---

The submersible motor is supplied pre-filled with a mixture of clear cold drinking water and anti-corrosive liquid.  
The following steps are executed prior to installation:

- ✓ Position the motor vertically on its base
- ✓ Check if all fasteners are tight. Tighten if required
- ✓ The two threaded plugs provided at the top are removed as shown in Fig. 5 below.



◀ **Fig. 5 Topping up the 3 inch Submersible Motor with Pure Drinking Water**

Check water level in the motor and if required, top up with clear drinking water  
Air bubbles, if any, are removed by gently rocking the motor to and fro

- ✓ The two threaded plugs are then re-assembled, ensuring the motor is encapsulated
- ✓ Dry the exterior of the motor and check thoroughly for water leakage
- ✓ If there is no leakage, the motor is now ready for coupling with the pump and then installation

## Checking Insulation Resistance

- ✓ Before submerging the unit, measure the insulation resistance using a megger of 1000 VDC
- ✓ Ensure contact points are clean
- ✓ Connect the measuring cable to the ground conductor
- ✓ Connect the other measuring cable to every core of the motor cable in succession
- ✓ Ensure that the insulation resistance, as shown on the Megger, is a minimum of 20MΩ

## Waterproofing the Submersible Motor Cable - Supply Cable Joint

---



Danger


Hazardous voltage will cause death, serious injury, electrocution.

Disconnect all power before working on this equipment and that it cannot be accidentally switched ON.


Refer the sequence shown in Fig. 6 below for insulating the cable joint for under water application:

**Procedure for joining and Insulating  
the 3 core conductors:**


**Step 1:** Soldering / knot the copper strands




**Step 2:** Layer 1 - 1st layer of virgin rubber insulation




**Step 3:** Layer 2 - 1st layer of PVC Insulation tape



**Step 4:** Layer 3 - 2nd layer of virgin rubber insulation




**Step 5:** Layer 4 - 2nd layer of PVC Insulation tape




**Procedure for joining and insulating  
the cable joint for under-water cable:**


**Step 6:** Layer 1 - 1st layer of virgin rubber insulation



**Step 7:** Layer 2 - 1st layer of PVC Insulation tape



**Step 8:** Layer 3 - 2nd layer of PVC Insulation tape



**Fig. 6 Cable Joint for under water application**



## Checking direction of rotation of Motor

---



Danger

Hazardous voltage will cause death, serious injury, electrocution.  
All electrical work must be performed by an authorized electrician in compliance with local electrical equipment standards & internal wiring codes.



After water-proofing the joint connecting the submersible motor cable and supply cable, check if the direction of rotation of the motor shaft matches the direction marked on the visible face of the top housing



The direction of rotation is counter-clockwise looking from the motor shaft end, as marked on the cable box



Connect the free ends of the cable to the control panel and energize the motor for a second or two



For added protection, continuously pour clean water over the sand guard to remove heat generated



Check the direction of rotation of the motor shaft



If the direction of rotation is in the same direction as that marked on the Top Housing exposed face, the connections are right



For Single-Phase models, in case the direction of rotation does not match the marking on the Top Housing, return the set back to the dealer from where it was purchased

## Coupling submersible motor to pump

---



Danger

Hazardous voltage will cause death, serious injury, electrocution.  
Disconnect all power before working on this equipment and that it cannot be accidentally switched ON.

To couple the submersible motor and pump, follow the following procedure:



The tripod with chain block is erected




Unpack the submersible pump and remove the cable guard and strainer

- ✓ Keep the submersible motor vertical
- ✓ Couplings are supplied mounted on the motor shaft
- ✓ Apply threading compound to the internal thread on the delivery casing and the external threaded portion of the short length delivery pipe to be fitted to the delivery casing
- ✓ Screw the short length of delivery pipe to the delivery casing

Refer Fig. 7 below for coupling the submersible motor to the pump:


- ✓ For motors with the coupling mounted on its shaft, carefully lower the pump while ensuring the pump shaft is aligned with the coupling till the inlet bracket bottom face sits on the top housing
- ✓ For pumps with the coupling mounted on its shaft, carefully lower the pump while ensuring the motor shaft is aligned with the coupling till the inlet bracket bottom face sits on the top housing
- ✓ Ensure that studs on the motor top housing should pass through the holes in the bottom portion of the inlet bracket and that the face of inlet bracket rests on motor top housing.
- ✓ Using hexagonal nuts, tighten the inlet bracket to top housing of the motor
- ✓ Check the play by lifting the coupling with pump shaft
- ✓ Lastly fit the cable guard and strainer back in position, ensuring that the cable is covered by the Cable Guard

✓ Fig. 7 Assembling submersible motor with coupling and pump



Fit the supporting clamp to the delivery pipe and suspend the submersible pump from the chain block (Refer Fig. 8)

✓ **Fig. 8 Typical tripod stand for lowering / lifting submersible pumpsets**



## Arrangement for installation



Use the services of a professional and trained mechanic with experience in erecting borewell submersible



While lowering the pumpset, ensure the cable does not get damaged



Use cable clips to keep the cable as close as possible to the pipe



Ensure the suspended submersible pump has a secondary support to prevent the set from falling to the bottom of the borewell

## Electrical installation

---

Check the power supply voltage and frequency and compare with the product requirements specified on the name plate.

- ✓ Observe relevant EB regulations while giving power supply to the motor
- ✓ Use a single cable from the control panel right up to the Submersible Motor
- ✓ Ground the Submersible Motor
- ✓ Ensure the joint is water proof as the cable joint is submerged in water
- ✓ The cable must not be coiled if it is of extra length. Any excess should be cut off before the connections are made
- ✓ Connect the cable properly to the starter terminals

## Control panel

---



Warning

Failure to use correct starting equipment and overloads may damage your Submersible Motor. This damage may not be covered by warranty.

It is recommended that the control panel shall incorporate the following:

- ✓ Contactors of sufficient current ratings with overload relay
- ✓ Over voltage and under voltage protection
- ✓ Phase failure protection
- ✓ Dry run preventer
- ✓ Ammeter and Voltmeter to display the current and voltage



## Cable Lead Wire Connection to Control panel

### Control panel

Cable	Terminal
Red	R
Yellow	Y
Blue	B

## Cable Selection

Refer TABLE 2 for the selection of cables from Control Panel to Submersible Motor:

### Submersible Cable Selection Chart (For 220 V, 50 Hz Ac power supply)

FL Current (Amps)	Motor Rating		Cable size in Sq.mm								
			1.5	2.5	4.0	6.0	10.0	16.0	25.0	35.0	50.0
	KW	HP	Maximum Length of Cable in Metres								
4.5	0.37	0.5	160	267	430	646					
5.4	0.55	0.75	133	222	359	538					
6	0.75	1	120	200	323	484	837				
9.5	1.1	1.5	75	126	204	306	529	835			
13	1.5	2	55	92	149	223	386	610	946		
20	2.2	3		60	96	145	251	396	615	866	
28	3.7	5			69	103	179	283	439	618	888

### Notes:

- Table shows maximum allowable length of submersible cable for the given full load current where site voltage is normal ie 220 V.
- For other voltages, the cable size is to be selected for the length which is calculated as follows.
- Calculated length =  $(220 / \text{Actual voltage}) \times \text{Actual length}$

## Electrical wiring work



Warning

All electrical work must be performed by an authorized electrician in compliance with local electrical equipment standards and internal wiring codes.

Improper wiring can lead to current leakage, electrical shock, or fire.

Provide a dedicated earth leakage circuit breaker, single phase preventer, dry run preventer and overload preventer for the submersible pump. Failure to follow this warning can cause electrical shock.

Operate well within the capacity of the power supply and wiring.

## Earthing



Warning

Be sure to install the ground wire securely. Failure to observe this precaution could damage the pump and cause current leakage which may lead to electrical shock



Caution

Do not connect the ground wire to a gas pipe, water pipe, lightning rod, or telephone ground wire. Improper grounding could cause electrical shock

## Connecting the power supply



Caution

Observe relevant Electricity Board regulations while powering up the Pumpset



Warning

Before inserting the power plug or connecting the wires to the terminal board, make sure the power supply is properly disconnected. Failure to do so may lead to electrical shock, short, or injury caused by the unintended starting of the pump



Caution

Do not use damaged cables, power plugs, or loose power outlets. Failure to observe this precaution could lead to electrical shock, short circuit or fire.

## Precautions during installation

---



Warning

When installing the pump assembly, ensure that it is suspended properly from the tripod stand or else the pump will fall into the bottom of the bore and which is difficult to retrieve. Provide backup suspension while lowering the pump



Caution

When installing or moving the pump, never suspend the pump by the cable. Doing so will damage the cable, which may cause current leakage, electrical shock, or fire

## Start-up

---



When the pump has been connected correctly, direction of rotation confirmed and is submerged in water, it should be started with the gate valve closed off to approximately 1/3 of its maximum volume of water



If there are impurities in the water, the valve should be opened gradually as the water becomes clearer



The pump should not be stopped until the water is clean, as otherwise the pump parts and the non-return valve may choke up



As the valve is being opened, the drawdown of the water level should be checked to ensure that the pump always remains submerged



The dynamic water level should always be above the inlet bracket



If the borewell yield is less than the discharge of the pump it is recommended to have a dry run protection device.



If the water level approaches the inlet bracket, there is likelihood of air being drawn into the pump along with water. This can reduce the life of hydraulic components and damage the pump.



Warning

If you find any abnormalities like vibration, noise, smell, etc. from the pump during trial operation, switch OFF the pump and contact the dealer where this pump was purchased.

# 11. Basic troubleshooting



Warning


To prevent serious accidents, disconnect the power supply before inspecting the pump.

Read this Operation Manual carefully before requesting repair. Contact the dealer where this equipment was purchased. Servicing and troubleshooting must be handled by qualified persons with proper tools and equipment. Common faults, root cause for these and suggested actions are provided in TABLE 3 below:

Fault	Possible causes	Suggested actions
The pump does not run	No electricity supply	Check the line. Contact the local EB authorities.
	Blown fuse	Check and replace / rectify the fuse
	Defective motor winding	Rewind the motor
	The motor control panel device is defective	Repair / replace the Control panel device
	Damaged coupling	Take out the pump set to check for coupling damage, replace coupling if necessary.
	The dry run protector has cut-off the electricity supply to the pump, due to low water level	Check the borewell yield, if the yield is less, reduce the discharge using a gate valve or wait for the water level to rise
	Faults in cable joints / Loose connections	Check the connections and make proper joints
	The motor starter overload has tripped	Reset the motor starter overload. If it trips again, check the voltage. If the voltage is OK, replace overload relay
	The ELCB has tripped out	Reset the ELCB, If trips again check the insulation resistance of the motor
Less discharge from pump	Available voltage is less	Check for loose connections or contact EB authorities. If needed, replace the cable.
	Increase in draw-down	Lower the pumpset or wait for water level to rise
	Leakage in pipes	Change the pipes which have leakages

<b>Fault</b>	<b>Possible causes</b>	<b>Suggested actions</b>
Less discharge from pump	Excessive wear of pump components mainly Impeller, wearing ring, etc. due to high sand content and prolonged operation	Replace the worn-out parts
	Discharge pipe coated with depositions	Clean the pipe and remove depositions
	Foreign bodies lodged in impellers	Lift the pump and clean the impellers
	The draw down is larger than anticipated	Lower the pump if specification meet the required head. If not, change the pump as per the required head.
	Wrong direction of rotation	For three phase, Interchange the supply connections of any two phases
	The valve in the discharge pipe are partly closed / blocked	Check and clean / replace the valves, if necessary
	The discharge pipe is partly choked by impurities	Check/replace the discharge pipe
	The NRV of the pump is partly blocked	Pull out the pump and check / replace the valve
	The pump and the riser pipe are partly choked by impurities	Pull out the pump. Check and clean or replace the pump, if necessary. Clean the pipes
	The pump is defective	Repair / replace the pump
Total head developed is too low	Excessive wear of pump components mainly Impeller, wearing ring, etc. due to high sand content and prolonged operation	Replace the worn-out pump parts
	Discharge pipe coated with depositions	Clean the pipe and remove the depositions
	Voltage too low	Check the voltage
	Defective rotor	Change the rotor
	Defective motor winding	Change the winding
	Damaged thrust bearing	Change the worn-out bearings



Fault	Possible causes	Suggested actions
The pump runs but no discharge	The discharge valve is closed	Open the valve
	No water or too low water level in the borehole	Lower the pump if head is within the specification
	The NRV is stuck in its shut position	Pull out then pump and clean / replace the valve
	The inlet strainer is choked up	Pull out the pump and clean the strainer
	The pump is defective	Repair / replace the pump
 Note	Conduct trial operation after maintenance	
 Note	Dispose replaced components and oil with appropriate care so as to protect the environment	
 Caution	Do not try to solve unspecified troubles of pump as it may lead to severe damage to the pump or injury to personnel. Contact the dealer where this pump was purchased	







## 12. Preventive maintenance checks

---

A definite schedule of preventive maintenance inspections should be established to avoid breakdown, serious damage and extensive downtime. The schedule will depend on operating conditions and experience with similar equipment. The below check list does not represent an exhaustive survey of maintenance steps necessary to ensure safe operation of the submersible pump.



Warning

The pump must not be operated with the delivery valve shut-off for more than a few seconds; otherwise the pump will overheat, possibly causing permanent damage



Warning

Utilise the services of an electrician to carry out electrical measurements / checking the functioning of the control panel



Taro Submersible Pumps do not require frequent maintenance



However, it is good practice to monitor the conditions and performance of the pump and motor

Diagnosis may be carried out by checking the following:



Close the delivery valve and check the shut-off head generated by the pump



Check the current drawn by the pump at the duty flow rate



Both these data should be compared to corresponding data recorded when the unit was initially installed



Any reduction in shut-off head may indicate wear of the pump hydraulics





Any increase in motor current at duty flow rate indicates a possible overload condition



Under running conditions, intentionally disconnect any one phase and check if Single Phase Preventer works

**Maintenance precaution**

 Warning	Disconnect the power supply before starting maintenance or inspection of the pump to avoid electrical shock
 Note	If you find any damages or abnormalities, switch OFF the pump and report the problem to the dealer from whom the set was purchased

NOTE: The manufacturer assumes no responsibility for damage or injury due to disassembly in the field.

## 13. Do's and don'ts

Do's	Don'ts
Prior to installation, check the water level in the submersible motor. If required, top up with clear and clean drinking water. Do not forget to replace the water filling plugs after filling	Do not erect the pumpset at the very bottom of the bore hole. Keep at least 3m bottom clearance
Check the direction of rotation of motor before coupling to the pump	Do not operate with the NRV and Strainer removed
Use proper size of cable from control panel to motor. Factor in operation at low-voltages	Do not permit use of multiple joints for making up the length of cable. Instead use a single cable from control panel to the submersible motor cable free end to reduce voltage drop
Connect the pump to a control panel with dry run and overload protectors	Do not operate the pump at shut-off conditions as the temperature of water will rise resulting in overheating of the components
Check the play and freeness of rotation of pump-motor shaft before installation	Do not test the pump outside the bore in dry condition as the seals and bearings will get damaged
Check for looseness of fasteners	Do not ground to a gas supply / water line
Check for leakages from motor	Do not lift / lower the product using the cable harness
When the drop cable must be spliced or connected to the motor leads, ensure that the splice is water tight.	Do not subject the product to shock loads
All wiring, electrical connections and system grounding must comply with local Electricity Board regulations. It is essential to ground the unit to prevent electrical shock. Provide earthing through the screws provided on the motor body	Do not attempt to repair the set. Approach the dealer from whom the set was purchased
For motors provided with a key, ensure the key is in place while coupling the pump and motor	Do not install the pump without checking the water level in the motor body
Ensure motor insulation resistance between phases and earth is greater than 20MΩ	Do not operate the pump with very low / intermittent discharge. In such cases throttle the discharge to avoid dry running

Do's	Don'ts
If a plastic well casing is used in your installation, ground the metal well cap or well seal	Do not perform frequent Megger tests on the winding as the winding insulation can weaken
When not in use, run the pump at least a few minutes a day	Do not use oversized fuse wires as this can cause the motor winding to be damaged due to starter failure / short circuiting

## 14. Important safety instructions

---

Only qualified personnel should be involved for inspection, maintenance and repairs. The successful and safe operation of such a product depends on proper handling, installation and maintenance. It is suggested that in case of non-functioning of the product, the customer is requested to contact the dealer through whom the purchase was made.



Danger

Hazardous voltage will cause death, serious injury, electrocution.  
Disconnect all power before working on this equipment.  
Maintenance should be performed by only qualified personnel.

## 15. Storage & handling



The submersible pumps are supplied from the factory in proper packing in which they should remain until they are to be installed



The product should be stored in a closed, dry and well ventilated room



Do not store the products in direct sunlight



Handle the pumps with care and do not expose the product to unnecessary impact and shocks



During unpacking and prior to installation, care must be taken when handling the pump to ensure that misalignment does not occur due to bending



If the product has been stored for a very long period, check the condition of the rubber gaskets, free rotation of the shaft, and level of water inside the motor



Caution

If the motors are stored, the shaft must be turned by hand at least once a month



Caution

If the motor has been stored for more than one year before installation, dismantle the motor and check the rotating parts and rubber components before use



Caution

After a long period of storage, the pump should be inspected before it is put in operation. Ensure the pump shafts rotate freely



Caution

The unit has water lubricated journal and thrust bearings and must never be run dry. Starting the pumpset for a short period without water must be avoided entirely as operation under such conditions will damage the bearings.



## 16. Company contact information

---

For most up to date information on Texmo Industries, please visit [www.taropumps.com](http://www.taropumps.com)



P.B.No. 5303,  
Mettupalayam Road,  
Coimbatore - 641 029, India

1800-102-8888  
[www.taropumps.com](http://www.taropumps.com)  
[info@taropumps.com](mailto:info@taropumps.com)



**Texmo  
Industries**  
Est. 1956